

Smoke Alarm Troubleshooting

Here is a quick guide to use if you are trying to figure out the sounds coming from your smoke or carbon monoxide alarms.

Alarm Sound Quick Guide

Smoke Alarm



- A continued set of three loud beeps - beep, beep, beep - means smoke or fire. Get out, call 9-1-1, and stay out.
- A single "chirp" every 30 or 60 seconds means the battery is low and must be changed.
- All smoke alarms must be replaced after 10 years.
- Chirping that continues after the battery has been replaced means the alarm is at the end of its life and the unit must be replaced.

Carbon Monoxide (CO) Alarm

- A continuous set of four loud beeps - beep, beep, beep, beep - means carbon monoxide is present in your home. Go outside, call 9-1-1, and stay out.
- A single chirp every 30 or 60 seconds means the battery is low and must be replaced.
- CO alarms also have "end of life" sounds that vary by manufacturer. This means it's time to get a new CO alarm.
- Chirping that continues after the battery has been replaced means the alarm is at the end of its life, and the unit must be replaced.

Additional information can be found on the [NFPA website](#) and below.

***** If you are a senior citizen over the age of 65 and need any assistance with your smoke or CO alarms, please call the fire department at (970) 686-2626.**

SMOKE ALARM TROUBLESHOOTING

Quick troubleshooting guide for the sounds coming from your smoke or carbon monoxide alarms



Call WSFR:

- ☎ If you are over 65 and need any assistance.
- ☎ If you have a smoke or CO alarm on a vaulted ceiling that you can't reach.
- ☎ If you have a malfunctioning smoke alarm that WSFR installed with the 2020 grant.

970-686-2626

DO NOT Call WSFR:

- ✗ If your alarm is chirping. The occasional chirp means the battery is low and must be changed. If you need a new smoke alarm or new batteries. These can be purchased online or at any local hardware store. The Red Cross can also provide these by calling **800-733-2767**.

Call 9-1-1:

- ☎ If your smoke alarm is going off but you DON'T see or smell smoke. BEEP BEEP BEEP means possible smoke or fire.

Related Questions

Do you replace smoke alarms?

We are happy to replace smoke alarms that we installed with the 2020 Grant for our senior citizens 65 and older. All smoke alarms provided by and installed with this grant are labeled as such.

Where can I buy new smoke alarms, and who can install them for me?

Smoke detectors and carbon monoxide alarms can be purchased at your local

hardware store or online. The Red Cross and its partners can also test existing smoke alarms and install up to three free smoke alarms for those that need them. 2. The Colorado Region will provide installation services in the Colorado region only. Click [here](#) for more information.

Can I get batteries from the fire department for my chirping alarm?

No.

My smoke detector randomly beeps in the night, then stops. What should I do?

Three loud beeps (BEEP BEEP BEEP) or a vocal detector that says FIRE FIRE FIRE means smoke or fire. Get out quickly and call 911. If it chirps, that means that the battery is low and must be

changed. Chirping that continues after the battery has been replaced means that the alarm is at the end of its life and must be replaced.

I have a smoke alarm that needs new batteries or replaced, and it is on a vaulted ceiling where I can't reach it. Can the fire department help?

If you have detectors that need installed and you can't reach them, the fire department can assist. If you have detectors that need a battery change and you have batteries that need installed, the fire department can assist. If you are a senior citizen over the age of 65 and need any assistance, please call the fire department at (970) 686-2626.

Why does the smoke alarm outside the bathroom door go off every time someone takes a hot shower?

If your smoke alarm is mounted near a bathroom, it is possible that steam from the shower has set off the alarm. Alarms should be placed at least 36 in. (910 mm) from the bathroom door to eliminate the nuisance alarms from steam. Areas of high humidity or spaces with a humidifier can also cause issues with the alarm. If the smoke alarm is installed near a cooking appliance (stove, oven, etc.) it could falsely alarm, so consider moving the alarm further from the appliance.

My carbon monoxide alarm is going off, but I don't smell anything. What should I do?

A continuous set of 4 beeps: BEEP BEEP BEEP BEEP (or a voice telling you CARBON MONOXIDE has been detected) means that carbon monoxide (CO) is present in your home. CO does not have an odor but can be deadly. Go outside immediately and call 9-1-1.

Do my household smoke alarms have batteries?

Yes. In residences, even though your smoke detectors are “hard-wired” into the household electrical system, smoke detectors are equipped with a battery backup. For optimal reliability,

WSFR recommends changing smoke detector batteries each time we change our clocks in the spring and fall for Daylight Savings Time. Change your clocks, change your batteries. During battery changes, take the time to remove any dust accumulation per the manufacturer's recommendations.

How long do smoke detectors last?

Smoke alarms have a service life of between 5-10 years depending on the manufacturer and model. Inspect the date on the smoke alarm and verify with the manufacturer's recommendation that the detector is within its service life. A detector that has exceeded its service life and is in use will give an indication or errantly generate alarms at some point.

[View All FAQ's](#)